



MOTOR section

COVFR section

COMPARTMENT

Level Control Compartment
HARD WIRE OPTION

(ON-OFF)<sup>0</sup>3 SWITCH

Supply Cable

(ALARM)

SWITCH

Alarm Yellow and Blue wires go to the alarm panel only Motor Control Red and Brown wires go to both alarm panel and motor contactor

> NA0036P12 B 120 Volt 60 Hz Control Wiring Tag

