


PIN	FUNCTION	2000S	EXTREME
1	MANUAL RUN	RED	BROWN
2	L1 (ACTIVE)	BLACK	RED
3	NEUTRAL	WHITE	BLACK
4	GND (EARTH)	GREEN	GRN/YEL
5	ALARM FEED	ORANGE	YELLOW
6	ALARM RETURN	BLUE	BLUE

NOTES:

- COMPONENTS NOT SHOWN IN ACTUAL LOCATIONS
- WHITE WIRES REPRESENTED AS LIGHT BLUE



POWER SOURCE
 L1 (ACTIVE)
 NEUTRAL
 GND (EARTH)
 DEDICATED 30A
 CIRCUIT BREAKER
 REQUIRED

ACTIVE
 NEUTRAL
 MAN RUN
 ALARM FEED
 ALARM RETN
 EARTH
 --PUMP--

REMOTE +
 SENTRY -
 DRY CONTACTS