


NOTES:

- COMPONENTS NOT SHOWN IN ACTUAL LOCATIONS
- WHITE WIRES REPRESENTED AS LIGHT BLUE

PIN	FUNCTION	2000S	EXTREME
1	MANUAL RUN	RED	BROWN
2	L1 (ACTIVE)	BLACK	RED
3	NEUTRAL	WHITE	BLACK
4	GND (EARTH)	GREEN	GRN/YEL
5	ALARM FEED	ORANGE	YELLOW
6	ALARM RETURN	BLUE	BLUE



POWER SOURCE  
 L1 ( ACTIVE )  
 NEUTRAL  
 GND ( EARTH )  
 DEDICATED 30A  
 CIRCUIT BREAKER  
 REQUIRED

ACTIVE  
 NEUTRAL  
 MAN RUN  
 ALARM FEED  
 ALARM RETN  
 EARTH  
 --PUMP--

LCD AND MEMBRANE RIBBON  
 CABLES ATTACH HERE

WP1  
 WP2

SERVICE NEUTRAL  
 MANUAL  
 ALARM FEED  
 ALARM RETURN

SWITCHED LAMP  
 MANUAL  
 ALARM BELL  
 BELL  
 24VDC MAX  
 SENTRY  
 DRY CONTACT  
 SILENCE SWITCH  
 + 12VDC BUZZER  
 CONECTOR  
 GROUND

REMOTE +  
 SENTRY -